

# BRAKE LIGHT BEZEL INSTALLATION

---

## NOTE:

- Handle with care
  - Protect your **Brake Light Bezel** from impact and excessive bending which will damage its appearance.
- 

## What you will need:

- Clean work area, free of airborne dust
  - Vehicle and **Bezel** Temperatures above 65°F
  - 3M Adhesive Cleaner (PN08984) or equivalent (optional)
  - Soft Clean Cloth
- 

## Pre-Installation:

- DO NOT remove the red tape liner until instructed to do so.
  - Lay out and test fit the **Bezel** before starting. Check that the shape and form of each piece properly conform to the surface area on both passenger and driver's side of the car. Note the proper placement and alignment.
  - Clean the receiving surface just prior to installation. Use 3M adhesive cleaner, or its equivalent, to clean the area thoroughly. The receiving surface must be dry and clean.
- 

## Installation:

- Remove the entire red liner. Protect the exposed tape from contaminants.
  - Hold the piece at a 90° angle to the application surface, making contact with the very top edge. Observe your placement and alignment guides. Adjust accordingly before the adhesive tape makes contact.
  - Once you get the placement right, press down across the top of the piece to tack it into place. Complete the installation by pressing down across the piece with a soft clean cloth, moving top to bottom.
  - Lastly, apply pressure over the entire surface including the edges to ensure that the tape completely adheres to the surface. Check your edges and reapply pressure where necessary.
  - You may use any non-abrasive stainless steel cleaner to keep your **Brake Light Bezel** shining bright!
- 

## IMPORTANT!

- Once the tape adheres to the vehicle, the **bezel** cannot be taken off without being damaged. The surface of the vehicle, however, will not sustain any damage if the **bezel** is removed in the future.